



MONSTER MNSPARK Spark Bluetooth Speaker User Manual

[Home](#) » [Monster](#) » MONSTER MNSPARK Spark Bluetooth Speaker User Manual 

Contents

1 MONSTER MNSPARK Spark Bluetooth Speaker User Manual

1.1 PACKAGE CONTENTS

1.2 PRODUCT CONTROLS

1.3 POWER

1.3.1 Charging

1.3.2 Power

1.4 AUDIO

1.4.1 Bluetooth Pairing

1.4.2 Bluetooth Audio Functions

1.4.3 EZ-Sync Pairing

1.5 FEATURE

1.5.1 Call Connectivity

1.6 SPECIFICATIONS

1.7 TROUBLESHOOTING

1.8 IMPORTANT SAFETY INSTRUCTIONS

1.9 FCC WARNING STATEMENT

1.10 IC WARNING STATEMENT

2 Documents / Resources

3 Related Posts

MONSTER MNSPARK Spark Bluetooth Speaker User Manual

MONSTER®

SPARK

Bluetooth Speaker

USER MANUAL



MODEL:MNSPARK

THANK YOU FOR CHOOSING MONSTER

Congratulations on your Monster Spark speaker! Please take your time to explore all of the features and utilities we have built into this product.

We put all of our products through rigorous testing and quality control. For your peace of mind, we offer a one-year limited warranty against manufacturing defects and workmanship.*

Please refer to the warranty section of the user manual for more details.

For more information on all of our products, please visit:

MyMonsterAudio.com

FOLLOW US:



@MyMonsterAudio



@MyMonsterAudio



@MyMonsterAudio

PACKAGE CONTENTS



Monster Spark Speaker
Altavoz Monster Spark
Haut-parleur Monster Spark



AUX cable 1.9 ft
Cable AUX 1,9 pies
Câble AUX 1,9 pi



5V 1A USB Charge Cord
(Port: USB to USB Type-C;
Length: 3.2 ft)

Cable de Carga USB 5V 1A
(Puerto: USB a USB Type-C;
Largo: 3.2 ft)

Câble de chargement
USB 5V 1A
(Prise: USB vers USB Type-C ;
longueur: 3.2 ft)




User Manual &
Quick Start Guide
(Incl. Warranty Statement)

Manual de Usuario y Guía
de Inicio Rápido
(Incluye Garantía Limitada)

Manuel de
l'utilisateur et Guide
de démarrage rapide
(Déclaration de Garantie Incluse)

PRODUCT CONTROLS



1. Microphone
2. Power Button
3. Power LED (Red)
4. Decrease Volume Button
5. Increase Volume Button
6. Bluetooth®/ EZ-Sync LED (Blue/Orange)
7. Bluetooth®/ EZ-Sync Button
8. Type-C USB Charge Port

POWER

IMPORTANT: Before first use, charge for 5 hours.

Charging

1 **CONNECT** the charge port (8) to an external power source using the included USB cable.



• **CHARGING, RED** LED (3) breaths on and off slowly.



(Breaths On/Off)

• **LOW** ($\leq 20\%$), **RED** LED repeatedly flashes.



(Flashes)

• **FULLY** charged, **RED** LED will stay on.



(Stays On)

Power

1 Turn the unit **ON**, press and hold the **POWER** Button (2) for 2 seconds.



(Hold 2 Sec.)

Unit will confirm with LED visual



(2 Sec. then Off)

• Turn the unit **OFF**, press and hold the **POWER** Button (2) for 3 seconds.



(Hold 3 Sec.)

Full Charge

- Up to **5** hours while powered **OFF**.
- Up to **12** hours while powered **ON**.

AUDIO

30 feet max connection range after pairing.

Devices out of range may suffer disruption or loss of signal.

Bluetooth Pairing

1 Place your smart device within **3 FEET** from the speaker.



*Make sure **Bluetooth** is enabled on your device.*



2 The speaker will automatically enter into Bluetooth® Mode and LED (6) will begin to blink when turned on.



(Blinking)

3 Select "**MONSTER SPARK**" from the Bluetooth® menu on your smart device.



Speaker will confirm connection with audible sound and LED (6) will remain solid.



(Stays On)

- **UNPAIR** device, press and hold the **BLUETOOTH®** Button (7) for 2 seconds.



(Hold 2 Sec.)

Speaker will confirm with audible sound and LED (6) will begin to blink.



(Blinking)

Bluetooth Audio Functions

- **PLAY/PAUSE** music, press **BLUETOOTH®** (7) button.



(Press)

- Select **NEXT** track, press and hold **INCREASE VOL.** (5) button for 2 seconds.



(Hold 2 Sec.)


- Select **PREVIOUS** track, press and hold **DECREASE VOL.** (4) button for 2 seconds.



(Hold 2 Sec.)

EZ-Sync Pairing

- 1 BLUETOOTH® PAIR**
 one Spark to be the **MASTER (A)**.
See Bluetooth® Pairing.

 - 2 TURN-ON** second Spark, place it in close proximity to the **MASTER (A)**.
 
 - 3 MASTER (A)**, Double-Click **BLUETOOTH®** Button (7), entering EZ-Sync search mode.
 
 (Press x2)
- | | | |
|--|---|---|
| Unit will make audio confirmation. | "Synchronized" | |
| 4 Once PAIRED ,
(A) speaker's BLUETOOTH® LED (6) will remain Blue and (B) speaker's LED (6) will stay on in Orange . | 
(Solid Blue) | 
(Solid Orange) |
| Unit will make audio confirmation. | "Synchronized" | "Synchronized" |
- UNPAIR** speakers,
 Double-Click **BLUETOOTH®** Button (7) of either unit.
 
 (Press x2)
- | | | |
|--|--|---|
| Units will make visual & audio confirmation. | 
(Solid) | 
(Flashing) |
|--|--|---|

FEATURE

Call Connectivity

- 1 ANSWER** phone calls while connected to Bluetooth by pressing the **BLUETOOTH®** Button (7).
 
 (Press)
- REJECT** phone calls by pressing and holding the **BLUETOOTH®** Button (7) for 2 Seconds.
 
 (Hold 2 Sec.)

SPECIFICATIONS

General	
Bluetooth® Version	5.0
Battery	3.6V 2500mAh
Speaker Drivers	1.75" Driver *2 + 1.5" tweeter *1
THD + Noise	≤10%dB
Materials	Plastic/Metal
Dimensions (H x W x D)	192.8*79.0*81.3 mm"
Weight	0.5 kg
S/N	>70dB
Power	20 Watts
IP Rating	IPX5

Operating Temperature	
Operating Temperature Range	32F° - 104F° (0°C - 40°C)
Operating Humidity Range	40~90% RH
Storage Temperature Range	-13F° to 158F° (-25°C - 70°C)

TROUBLESHOOTING

Speaker is not powering on	• Make sure POWER ADAPTER is fully inserted into the unit (See pg. 1)
Buttons are not responding	• Reset the speaker by turning the power OFF, and then back ON. (See pg. 1) • Unplug the POWER ADAPTER, then plug it back in. (See pg. 1)
No music is playing	• Make sure the speaker is set to the same source as your audio device. • Make sure the VOLUME level is high enough on your audio device as well as the speaker.
Bluetooth® audio quality is poor	• Move your music device closer to the speaker. • Remove objects that may be interfering with the wireless connection.
Bluetooth® device is not pairing	• Verify that the speaker and your device have BLUETOOTH® mode active. (See pg. 2) • Make sure the speaker and/or your device is not already paired with another device. • Check that the speaker is in pairing mode. (See pg. 2) • Turn the speaker OFF, and then back ON. Press and hold the BLUETOOTH® button to manually enter pairing mode. (See pg. 2)
Contact our support team for additional services	Call: 1-800-976-0677 Email: support@mymonsteraudio.com Hours of Operation: Monday - Friday: 7:00 am - 4:00 pm (PST) Saturday - Sunday: CLOSED

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. This apparatus can be used in wet location conditions after disconnected the AC Mains supply and closing the water proof cap for the AC inlet. It must not be used in wet location conditions when charging. Do not use this apparatus near water-The appliance should not be used near water or moisture – for example, in wet basement or near a swimming pool.
6. Clean only with dry cloth.
7. Do not block any ventilation openings, install in accordance with the manufacturer's instructions.

8. Do not install near any heat sources such as radiations, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protected the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lighting storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Mains plug is used as the disconnect device, the disconnect device shall remain readily operable.
16. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions at open site. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloth, curtains, etc.
17. No naked flame sources, such as lighted candles, should be placed on the apparatus.
18. Attention should be drawn to the environmental aspects of battery disposal.



WARNING: The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. Protective earthing terminal. The apparatus should be connected to a mains socket outlet with a protective earthing connection.



Protective earthing terminal. The apparatus should be connected to a mains socket outlet with protective earthing connection.

FCC WARNING STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING STATEMENT

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

FCC RADIATION EXPOSURE STATEMENT This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.



WARNING

Prevent fire and shock hazards. Do not use extension cords or outlets that expose plug blades. Do not expose cables and plugs to rain or moisture.

Do not attempt to perform any servicing that is not included in the operating instructions. Do not attempt to replace the battery, as incorrect installation can cause fire or explosion. For service, contact qualified service personnel.

Do not remove cover or back of product. There are no user-serviceable parts inside. Attempting to modify controls or performance beyond manufacturer specifications may result in hazardous exposure to radiation.

Documents / Resources



[MONSTER MNSPARK Spark Bluetooth Speaker](#) [pdf] User Manual
MNSPARK, 2AAIN-MNSPARK, 2AAINMNSPARK, MNSPARK Spark Bluetooth Speaker, Spark Bluetooth Speaker